

# COVER'S

Tape alignment procedure:

- Determine the starting point in front of the leading edge of the wing (DOT) ●
- Determine your end point (DOT) ●
- Measure the overall circumference of the torso at the points ● to determine the length of the rubber bands
- The line between the points serves as a basic sighting line
- Select several points along the line (write the indentation in the form) XYZ .....
- At XYZ points, measure the distance DOT to DOT ● ●
- Select the number of points as required. However, the finer the measurement, the more accurate the result will be

